# ABS HUT-1 INDICATION PANEL

UP ⟵ ⟶ DOWN

SIGNALS FED FROM HUT:
UP: 4161,4171,4181,4191.
DOWN: 4172,4182,4192,4202.

OUTGOING TO

| S18 | |
|---|---|
| HYK | |
| HHYK | |
| DYK | |

| 4172-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

| 4182-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

| 4192-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |


| 4202-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

INCOMING TO

| 4202 | |
|---|---|
| HYK | |
| HHYK | |
| DYK | |

ABS HUT-1

Km.418/16-18




INCOMING TO

| 4161 | |
|---|---|
| HYK | |
| HHYK | |

| 4171 | |
|---|---|
| DYK | |

| 4161-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

| 4171-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

| 4181-TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

| 4191TS | | | | | |
|---|---|---|---|---|---|
| SYSTEM-A | | | SYSTEM-B | | |
| CLR | OCC | PPK | CLR | OCC | PPK |

OUTGOING TO

| 4201 | |
|---|---|
| HYK | |
| HHYK | |
| DYK | |